

Option bit assignments

10/20/69

bit number	Event Channel	C-list	Operation	File	Sub-Process	Process
0	destroy	destroy	destroy	destroy	destroy	destroy
1	put event	copy into	add order	write	change map	interrupt
2	get event or hang	copy out of	copy	read	set p- counter	
3	get event or FRETURN	use as subp local c-list	change PS any \leftarrow UDAT/VCAP	place in map	set ESM	
4			change PS any \leftarrow UCAP	add block	create "son" subprocess	
5			change PS UDAT \leftarrow FDAT	delete block	call/jump	
6			change PS UCAP \leftarrow FCAP		jump	
7					jump return	
8					set temp parent	
9					use to name father subp	
10					can be named as interrupt subp	
11						
12						